## Instructions for 10K Weatherproof Temperature Probe (FGD-0102)

Probe comes with 12 feet of 24 gauge wire and mounting hardware.

## Instructions for Express II

- 1. Remove any existing wires or sensors from the input terminal.
- 2. Place the corresponding input shunt in the "a" position for Express II.
- 3. Program the input type for a 10K thermistor in either Fahrenheit or Celsius.

## Instructions for 1400, 1800, 2800, WEB600, Sentinel, Sentinel Pro, and Stratus EMS

The probe may be connected to any available input/zone terminal. Refer to your user's manual for configuration and programming. To connect the probe:

- 1. Remove any existing wiring or sensors from the input terminal.
- 2. Attach wires from the weatherproof temperature probe to the input terminal and ground terminal respectively.

Warning: Do not submerge.

© 2007 Sensaphone 901 Tryens Road, Aston, PA 19014 For Technical Support call 877-373-2700 or E-mail support@sensaphone.com

## **10K** Weatherproof Temperature Probe

LIT-0056