

## **Instructions for Weatherproof 2.8K Temperature Probe (FGD-0101)**

Probe comes with 12 feet of 24 gauge wire and mounting hardware.

### **Instructions for Models 400, 800, 1400 and 1800**

The probe may be connected to any available input terminal. Refer to your user's manual for configuration and programming. To connect the probe:

1. Remove any existing wiring or sensors (including local thermistor) from the input terminal.
2. Attach wire from the weatherproof temperature probe to the input terminal and ground respectively.

### **Instructions for WEB600, CELL682, Express II and Sentinel**

The probe may be connected to any available input terminal. Refer to your user's manual for configuration and programming. To connect the probe:

1. Remove any existing wiring or sensors from the input terminal.
2. Attach wire from the weatherproof temperature probe to the input terminal and ground respectively.
3. Program the input type for a 2.8K thermistor in either Fahrenheit or Celsius.

Additional wire (FGD-0010) and wire nuts can be used to extend the wire length.

**Warning:** Do not submerge.

© 2007 Sensaphone 901 Tryens Road, Aston, PA 19014

For Technical Support call 877-373-2700 or E-mail [support@sensaphone.com](mailto:support@sensaphone.com)

# 2.8K

## Weatherproof Temperature Probe

LIT-0055