



## Monitor temperature ranges

The Temp Alert Temperature Switch can be used with all Sensaphone models to monitor air temperature from 20° to 110°F. Simply set the acceptable temperature limits for your application and when the temperature exceeds that setting, the sensor triggers an alarm. It requires no power for operation and multiple units may be wired in series to a single input.

## **TECH SPECS**

Name	TempAlert Temperature Switch
Sensor Temperature Range	20° to 110°F   -34° to 54°C
Accuracy	± 3°F   ±1.7°C
Connection	Hardwired
Housing	Plastic
Dimensions	4.5 x 3.25 x 1"   11.4 x 8.3 x 2.5 cm
Sensor Series	Contact Series

All specifications subject to change without notice

Product Name Part Number



Family owned and made in the USA since 1985

901 Tryens Road

Phone: 877-373-2700

Aston, PA 19301 Web: sensaphone.com

